

The device is very easy to operate, just 3 steps:

- 3 steps to operate:
- 1.set cleaning time
 - 2.set Drying time
 - 3.press START

An Easy Operation Machine

3 steps to operate:

- 1.set cleaning time
- 2.set Drying time
- 3.press START



Pneumatic Stencil cleaner



Only Pneumatic Closed-loop water



Cleaning Flow Chart

```

    graph TD
      A[Press START] --> B[Pump Pressure work]
      B --> C[Pump Liquid]
      C --> D[Liquid pass filter]
      D --> E[Spray nozzle work]
      E --> F[Cleaning Mesh]
      F --> G[2mm/1mm Filter]
      G --> A
    
```

BEFORE AND AFTER CLEANING



